

AIRSTOP DIVA Vapour Barrier

is a moisture-variable vapour barrier for use in the air-tight layer. The functional membrane changes its diffusion resistance depending on the current humidity. During the winter months room atmosphere is generally dryer. The sd-value of the vapour barrier increases. This process results in the penetration of only a little water vapour into the construction and/or into the insulation. In summer, when there is sufficient solar insolation, the relative humidity behind the membrane is higher as a result of reverse diffusion. The water molecules are stored in the membrane. The sd-value sinks, causing more water vapour to escape from the construction and into the rooms and the building element becomes dryer.

ADVANTAGES

- transparent
- moisture-variable with a very high sd-value range
- printed cutting line

FIELDS OF APPLICATION

- flat roofs
- construction components with permeable and impermeable outer shell in new constructions and refurbishment






RECOMMENDED ACCESSORIES



AVAILABLE IN THE FOLLOWING DIMENSIONS

Roll width	3,00 m	3,20 m	3,20 m
Roll length	100 m	40 m	100 m
Roll area	300 m ²	128 m ²	320 m ²
Roll weight	26,5 kg	11,5 kg	28 kg

PRODUCT DATA ACCORDING TO STANDARD EN 13984

Composition	Fleece composite made of polymers	
Weight per unit area ISO 536	86 g / m ² (± 5%)	
Temperature resistance	- 40 °C - + 80 °C	
Storage	cool and dry	
Sd-value (moisture-variable)	0,5 - 30 m	
Colour	transparent white with blue print	
Tear strength EN 12311-2	 180 N/50 mm	
	 125 N/50 mm	
Elongation at maximum EN 12311-2	 68 %	 79 %
	 140 N	 150 N

GUIDELINES FOR THE USE OF AIRSTOP VAPOUR BARRIERS

Vapour barriers can be used with wall, roof and ceiling construction elements as an airtight layer and as a vapour retarding layer.

ATTACHMENT TO THE SUB-SURFACE

(1) MECHANICAL ATTACHMENT OF THE VAPOUR BARRIER

The vapour barrier is usually attached transverse to the position of the rafters, joists or beams with the smooth and/or printed side facing the installer. The lengths are fixed mechanically to the construction's wood with approx. 10cm overlap using tacking staples. For metal C-studs a temporary attachment using double-sided adhesive tape or even a spray-on contact adhesive is a possibility.

(2) AIRTIGHT ADHESION

Airtight adhesion of the joints, connections and penetration points must be carried out using the AIRSTOP adhesion system.

(3) TRANSVERSE LATHING / MOUNTED AT INTERVALS

The laths underneath the vapour barrier have to be mounted before the cellulose is blown in. The centre distance shall be less than 40cm. The joints of the vapour barrier also have to be covered by an additional lath. Glued connections and joints that were under tension have to be mechanically secured. The membrane has to be applied without tension.

**Exception: for AIRSTOP DIVA FORTE distance is 30 cm c-to-c*

(4) LONGITUDINAL LATHING

When no transverse lathing is used, e.g. if formwork is installed on longitudinal lathing, the vapour barrier must be placed parallel to the rafters or to the construction. The joints must lie on the wood of the construction and be stapled overlapping and sealed using AIRSTOP adhesive tape. Before the insulation is blown in the longitudinal lathing must be mounted to provide mechanical relief of the joints.

For detailed solutions please go to www.isocell.at or ask for our brochure "Air-tightness in Detail".



ISOCELL GmbH
Gewerbestraße 9
5202 NEUMARKT AM WALLERSEE | Österreich
Tel.: +43 6216 4108 | Fax: +43 6216 7979
office@isocell.at

ISOCELL SCHWEIZ AG
Herbergstrasse 29
9524 ZUZWIL | Suisse /Schweiz
Tel.: +41 71 544 47 20
office@isocell.ch

ISOCELL FRANCE
170 Rue Jean Monnet | ZAC de Prat Pip Sud
29490 GUIPAVAS | France
Tél.: +33 2 98 42 11 00 | Fax: +33 2 98 42 11 99
contact@isocell-france.fr

ISOCELL BUREEL BELGIË
Außenborner Weg 1 | Schoppen
4770 AMEL | Belgique
Tel.: +32 80 39 90 58 | Fax: +32 80 39 97 68
office@isocell.be

ISOCELL Sverige AB
Gamla Stallet | Stora Väsby
194 37 UPPLANDS VÄSBY | Sverige
Tel.: +46 10 130 25 01
office@isocell.se

ISOCELL
www.isocell.com